



Bow number application:

Step 1: Measure the area where bow number will be applied on each side as per diagram in Fig 1. The aft edge of the sticker is not to be placed any further aft than 1300mm from the bow and no lower than 20mm from the deck level. No part of the number shall be wrapped over the edge of the deck.

Step 2: Clean hull surface with Acetone and clean cloth removing any polish or anything that might prevent sticker from adhering properly.

Step 3: Spray or apply some soapy water on the application area. Position the sticker in the required area and apply while the surface is still wet. With a plastic card or scraper remove any air bubbles or lines that might be trapped between the sticker and hull. Best procedure is to work from the middle of the sticker and work bubbles towards the sticker edge. Repeat on each side of the hull.

FIG 1

